



I built a Blinking test based on the tutorial. In the device, I chose Raspberry Pi instead of forte\_PC



After I deploy the function block, the forte in the Raspberry Pi can run, and can I see that the pin port is enabled?



This is the IO information of my Raspberry Pi

```
pi@raspberrypi:~ $ gpio readall
```

BCM	wPi	Name	Mode	V	Physical	V	Mode	Name	wPi	BCM
		3.3v			1	2		5v		
2	8	SDA.1	IN	1	3	4		5v		
3	9	SCL.1	IN	1	5	6		0v		
4	7	GPIO. 7	IN	1	7	8	0	IN	TxD	15
		0v			9	10	1	IN	RxD	16
17	0	GPIO. 0	IN	0	11	12	0	IN	GPIO. 1	1
27	2	GPIO. 2	IN	0	13	14		0v		18
22	3	GPIO. 3	IN	0	15	16	0	IN	GPIO. 4	4
		3.3v			17	18	0	OUT	GPIO. 5	5
10	12	MOSI	IN	0	19	20		0v		24
9	13	MISO	IN	0	21	22	0	IN	GPIO. 6	6
11	14	SCLK	IN	0	23	24	1	IN	CE0	10
		0v			25	26	1	IN	CE1	11
0	30	SDA.0	IN	1	27	28	1	IN	SCL.0	31
5	21	GPIO.21	IN	1	29	30		0v		1
6	22	GPIO.22	IN	1	31	32	0	IN	GPIO.26	26
13	23	GPIO.23	IN	0	33	34		0v		12
19	24	GPIO.24	IN	0	35	36	0	IN	GPIO.27	27
26	25	GPIO.25	IN	0	37	38	0	IN	GPIO.28	28
		0v			39	40	0	IN	GPIO.29	29